





Combination Lock Directions - 3 Wheel S & G Style

	<p>Turn the dial to the LEFT more than 4 times:</p> <p>Pass through the first combo number 3 times, then set the combo number at notch</p>	
	<p>Turn the dial to the RIGHT 3 times:</p> <p>Pass through the second combo number twice, then set the 2nd combo number at the notch.</p>	
	<p>Turn the dial to the LEFT 2 times:</p> <p>Pass through the third combo number once, then set the third combo number at the notch.</p>	
	<p>Turn the dial to the RIGHT SLOWLY until the dial stops. The combination lock is now open. If the lock spins freely, then the correct sequence or combination has been used.</p>	
	<p>You should now be able to turn the handle and open the safe. Please keep your combination in a safe place, away from your safe.</p>	